# **Oriental motor**

### Servo Motors

# **AZX** Series

# Battery-Free Absolute Mechanical Sensor Equipped Motor

# Standard Type / PS Geared Type 400 W, 600 W

These servo motors are equipped with a battery-free absolute sensor.

They are suitable for positioning applications with a large amount of travel, since they achieve high torque in the high speed range.

The basic operations are the same as the **AZ** Series, making combined use in equipment easy.





### Battery-Free Absolute Sensor Equipped Servo Motor

The **AZX** Series is equipped with the same battery-free mechanical absolute sensor (**ABZO** sensor) as the **AZ** Series. These are dedicated servo motors for positioning and continuous operation.



- Mechanical-Type Sensor
   Holds positioning information even when powered off
- Multi-Turn Absolute Sensor
   Absolute position detection is possible with ±900 rotations (1800 rotations) of the motor shaft from the reference home position
- For details about the advantages, please see the Oriental Motor website.

#### No External Sensors Required

Thanks to the absolute system, a home sensor or external sensor is not required.

#### Advantages

- High-Speed Return-to-Home + Improved Return-to-Home Accuracy
- Reduced Cost
- Simple Wiring
- Not Affected by External Sensor Malfunctions

#### Battery-Free


No battery is necessary for a mechanical-type sensor. Positioning information is managed mechanically by the ABZO sensor.

#### Advantages

- No Battery Replacement Required
- No Battery Installation Space Required (Unlimited driver installation possibilities)
- Safe for Overseas Shipping


#### **Network Compatible Drivers**

These drivers are EtherCAT and EtherNet/IP-compatible. The host control device and driver are connected with one communication cable, reducing wiring.



## Sequence Function Simplifies Programming\*

**AZX** Series positioning operations come with a variety of sequence functions, such as a timer setting between operations and linked operation, conditional branching, and loop counting. These can be set using the support software **MEXEO2**, which helps simplify the host system's sequence program. \*Only EtherNet/IP-compatible drivers.



END


- Positioning Operation Data Setting (Max. 256 points)
- General-Purpose I/O Signal Counts (Input 6, output 6)
- Communication I/O Signal Counts (Input 16, output 16)

#### Achieves High Torque in the High Speed Range


The **AZX** Series achieves high torque in the high speed range.

It is suitable for positioning applications with a large amount of travel (e.g.: ball screw driving).

#### Standard Type








■This is a comparison of the speed – torque characteristics of the AZX Series and AZ Series.

The AZX Series offers superior torque in the high speed range, the AZ Series is better in the low speed range.

#### The Basic Operations are the Same as the AZ Series

Using the AZX Series and AZ Series together in the same equipment can eliminate the work of operational changes.



#### **Product Line**

Motors, drivers, and cables must be ordered individually.


Motor					Cables	
Туре	Output Power	Frame Size	Driver		Cable Type	Cable Length
Standard Standard Type with Electromagnetic Brake	400 W	60 mm		Connection Cable Sets	-For Motor / Encoder	_
	600 W	85 mm			-For Motor / Encoder / Electromagnetic Brake	
PS Geared PS Geared Type with Electromagnetic Brake  -Gear Ratio 5 10 25	400 W	90 mm	EtherNet/IP  Single-Phase/ Three-Phase	Flexible Connection	-For Motor / Encoder	1 to 20 m
3 10 23	600 W	90 mm*	200-240 V	Cable Sets	-For Motor / Encoder / Electromagnetic Brake	

- EtherCAT-compatible drivers have passed the official EtherCAT conformance test.
- EtherCAT® is a patented technology licensed from Beckhoff Automation GmbH (Germany) and is a registered trademark of that company.
- ■EtherNet/IP™ is a trademark of ODVA.
- ★Gear ratio 5 only

#### System Configuration

Combination of Standard Type Motor with Electromagnetic Brake and Network Compatible Driver

An example of a configuration using I/O control or EtherNet/IP with an EtherNet/IP compatible driver is shown below. Motors, drivers, and connection cable sets / flexible connection cable sets must be ordered individually.



<sup>■</sup>The system configuration shown above is an example. Other combinations are also available.
Note

The motor cable and electromagnetic brake cable from the motor cannot be connected directly to the driver. When connecting to a driver, use a connection cable.

#### Product Number

Motor

# **AZXM 6 40 A C**

① 2 3 4 5

**○PS** Geared Type

# **AZXM 9 40 A C-PS 10**

① 2 3 4 5 6 7

1	Motor Type	AZXM: AZX Series Motor
2	Motor Frame Size	<b>6</b> : 60 mm <b>9</b> : 85 mm
3	Output Power	<b>40</b> : 400 W <b>60</b> : 600 W
4	Output Shaft Type	A: Single Shaft M: Type with Electromagnetic Brake
(5)	Motor Type	C: AC Input Specification

1	Motor Type	AZXM: AZX Series Motor
2	Motor Frame Size	<b>9</b> : 90 mm
3	Output Power	<b>40</b> : 400 W <b>60</b> : 600 W
4	Output Shaft Type	A: Single Shaft M: Type with Electromagnetic Brake
(5)	Motor Type	C: AC Input Specification
6	Geared Type	PS: PS Geared Type
7	Gear Ratio	

1	Driver Type	AZXD: AZX Series Driver
2	Power Supply Input	S: Single-Phase/Three-Phase 200-240 VAC
3	Product Line	ED: EtherCAT-Compatible EP: EtherNet/IP-Compatible

1		CC: Cable	
2	Length	010:1 m 020:2 m 030:3 m 050:5 m 070:7 m 100:10 m 150:15 m 200:20 m	
3	Reference Number		
4	Applicable Model	X: For AZX Series	
(5)	Cable Type	<b>F</b> : Connection Cable Set <b>R</b> : Flexible Connection Cable Set	
6	Description	Blank: For Type without Electromagnetic Brake  B: For Type with Electromagnetic Brake	

#### Driver

# **AZXD-S EP**

1

2 3

Connection Cable Sets / Flexible Connection Cable Sets

**CC 010 V X F B** 

1

#### Product Line

Motors, drivers, and connection cables must be ordered individually.

#### Motor

#### 

Frame Size	Output Pow	er Product Name
60 mm	400 W	AZXM640AC
85 mm	600 W	AZXM960AC



#### ◇PS Geared Type

Frame Size	Output Power	Product Name
90 mm	400 W	AZXM940AC-PS5 AZXM940AC-PS10 AZXM940AC-PS25
	600 W	AZXM960AC-PS5



V //		3
Frame Size	Output Power	Product Name
60 mm	400 W	AZXM640MC
85 mm	600 W	AZXM960MC



#### ◇PS Geared Type with Electromagnetic Brake

Frame Size	Output Power	Product Name
90 mm	400 W	AZXM940MC-PS5 AZXM940MC-PS10 AZXM940MC-PS25
	600 W	AZXM960MC-PS5



#### Driver

#### 

Power Supply Input	Product Name
Single-Phase/Three-Phase 200-240 VAC	AZXD-SED

#### 

Power Supply Input	Product Name
Single-Phase/Three-Phase 200-240 VAC	AZXD-SEP

#### Connection Cable Sets / Flexible Connection Cable Sets

Use the flexible connection cable set in applications where the cable is bent and flexed.

Extension cable sets and flexible extension cable sets are also available.

Refer to page 22.

#### Included Items

#### Motor

Туре	ncluded Items Parallel Key
Standard Type	-
PS Geared Type	1 piece

#### Driver

Туре	Included Items	Connector
EtherCAT-Compatible EtherNet/IP-Compatible		-For CN1 (1 piece) -For CN4 (1 piece) -For CN7 (1 piece) -Connector wiring lever (1 piece)

#### List of Combinations

Product	Туре	Product Name	
Motor	Standard Type	AZXM640@C, AZXM960@C	
Motor	PS Geared Type	AZXM940IIC-PS , AZXM960IIC-PS5	
		+	
Product	Туре	Product Name	
Driver	EtherCAT-Compatible	AZXD-SED	
Driver	EtherNet/IP-Compatible	AZXD-SEP	
		+	
Product	Туре	Product Name	
Connection Cable Sets /	Connection Cable Set	For Motor / Encoder: CC VXF For Motor / Encoder / Electromagnetic Brake: CC VXFB	
Flexible Connection Cable Sets	Flexible Connection Cable Sets	For Motor / Encoder: CC VXR For Motor / Encoder / Electromagnetic Brake: CC VXRB	

A letter or number indicating the following is specified where the box is located in the product name.

■: Output Shaft Shape

☐: Gear Ratio

# **How to Read Specifications**

	Motor Product Name		Single Shaft		AZXM640AC	AZXM940AC-PS5
			With Electromagnetic Brake		AZXM640MC	AZXM940MC-PS5
	Driver Pro	duct Name			AZX	D-S
<u> </u>	Rated Out	put Power		W	400	400
_	Rated Spe	ed	r,	/min	3000	-
—	Max. Spee	ed	r,	/min	5500	-
_	Rated Tor	que		Nm	1.27	5.72
_	Maximum	Instantaneous Torque		Nm	3.82	17.1
-	Permissib	le Speed Range	r	/min	-	0 - 1100
_	Rotor Iner	tia	J: k	gm <sup>2</sup>	0.294×10 <sup>-4</sup> [0.316×10 <sup>-4</sup> ]	0.294×10 <sup>-4</sup> [0.316×10 <sup>-4</sup> ]
_	Inertia		J: kı	gm <sup>2</sup>	-	0.163×10 <sup>-4</sup>
_	Permissib	le Load Inertia	J: k	gm <sup>2</sup>	14.7×10 <sup>-4</sup>	0.037
_	Gear Ratio				-	5
_	Resolution	1		P/R	100 - 10000 (Factory setting 1000)	500 - 50000 (Factory setting 5000)
	Detector					urn Absolute Encoder 900 rotations (1800 rotations)
_	Backlash		arc	cmin	-	15
	Power	Main Power Supply	Input Voltage		Single-Phase/Three-Phase 200	-240 VAC -15 - +6% 50/60 Hz
	Supply	Ivialii Fowei Supply	<ul> <li>Rated Current</li> </ul>	Α	Single-Phase: 5.3	Three-Phase: 3.0
	Input	Control Power	Input Voltage		24 VD	C±5%
		Supply	Input Current	Α		[0.57]
			Туре		Power Off A	ctivated Type
			Power Supply Input		24 VD0	±10%
	Flectroma	anetic Brake	Power Consumption	W	7	.2
	Licotronia	gnotio brano	Rated Current	Α	0	.3
			Static Friction Torque	Nm	1.27	

#### (1) Rated Output Power

This is the permissible range the temperature rise may not exceed when continuously operated at the motor's rated speed and rated torque.

#### 2 Rated Speed

This is the rotation speed when the motor is operated at rated output power.

#### 3 Max. Speed

This is the maximum rotation speed the motor can turn at.

#### (4) Rated Torque

This is the output torque when the motor is operated at rated output power and rated speed.

#### **5** Maximum Instantaneous Torque

This is the maximum torque that can be used instantaneously (in a short period of time).

It is the maximum for acceleration and deceleration, and up to this torque can be used.

#### 6 Permissible Speed Range

This is the range of the operable rotation speed on the output gear shaft.

#### (7) Rotor Inertia

This refers to the inertia of the rotor inside the motor.

This is necessary when the required torque (acceleration torque) for the motor is calculated.

#### ® Inertia

This is the inertia in the gearhead.

This is necessary when the required torque (acceleration torque) for the motor is calculated.

#### Permissible Load Inertia

This is the load inertia that the motor can stably control. Control can become unstable if a load exceeding this value is applied, resulting in speed regulation variation and issues with protection circuit operation, vibration, etc.

#### 10 Gear Ratio

This is the ratio of the rotation speed between the input speed from the motor and the speed of the output gear shaft. For example, a gear ratio of 10 indicates that when the input speed from the motor is 10 r/min, the output gear shaft speed is 1 r/min.

#### (1) Resolution

This indicates the angle of rotation of the output shaft in one pulse. For example, if the resolution = 1000 p/rev, one rotation of the motor (360°) can be divided into 1000.

#### 12 Backlash

This is the play of the output gear shaft when the motor shaft is fixed.

When positioning in bi-direction, the positioning accuracy is affected.

#### **3** Rated Current


This is the input current of the main power supply required for use in the continuous duty region.

#### (4) Static Friction Torque

This is the electromagnetic brake specifications. It is the maximum holding torque (holding force) at which the electromagnetic brake can hold position.

# **How to Read Speed - Torque Characteristics**

#### AZXM640□C



#### ① Continuous Duty Region

This is the region that can be used at continuous rating. The effective load torque must be corrected to this region.


#### 2 Limited Duty Region

This is the region used for acceleration and deceleration.

#### ③ Rated Torque

This is the output torque when the motor is operated at rated output power and rated speed.

#### AZXM940 C-PS5



#### 4 Maximum Instantaneous Torque

This is the maximum torque that can be used instantaneously (in a short period of time).

It is the maximum for acceleration and deceleration, and up to this torque can be used.

# **Standard Type**

#### Frame Size 60 mm

#### Specifications

c**™**us C€

Motor Product Name		Single Shaft		AZXM640AC	
WOLDI FIOUUCI I	Name	With Electromagnetic B	rake	AZXM640MC	
Driver Product I	Name			AZXD-S	
Rated Output P	ower		W	400	
Rated Speed			r/min	3000	
Max. Speed			r/min	5500	
Rated Torque			Nm	1.27	
Maximum Insta	ntaneous Torque		Nm	3.82	
Rotor Inertia		J: kgm <sup>2</sup>		0.294×10 <sup>-4</sup> [0.316×10 <sup>-4</sup> ]* <sup>1</sup>	
Permissible Inertia*2			J: kgm <sup>2</sup>	14.7×10 <sup>-4</sup>	
Resolution			P/R	100 - 10000 (Factory setting 1000)	
Detector				Mechanical Multi-Turn Absolute Encoder 1 Turn: 16 bit Multi-Turn: ±900 rotations (1800 rotations)	
	Main Dawer Cumply	Input Voltage		Single-Phase/Three-Phase 200-240 VAC -15 - +6% 50/60 Hz	
Power Supply	Main Power Supply	Rated Current*3	Α	Single-Phase: 5.3 Three-Phase: 3.0	
Input	Control Power	Input Voltage		24 VDC±5%	
	Supply	Input Current	Α	0.27 [0.57]* <sup>1</sup>	
		Туре		Power Off Activated Type	
		Power Supply Input		24 VDC±10%	
Electromagnetic	c Brake <sup>≭4</sup>	Power Consumption	W	7.2	
		Rated Current	Α	0.3	
		Static Friction Torque	Nm	1.27	

A letter indicating the driver type is specified where the box I is located in the product name. Check "List of Combinations" on page 5 for driver product names.

#### Note


When the motor is continuously operated at rating, a heat sink of a capacity at least equivalent to an aluminum plate of the following size is required.

AZXM640□C: 300 mm×300 mm, 10 mm thick

#### Speed – Torque Characteristics

#### AZXM640□C

Power supply specification: Three-phase/single-phase 200-240 VAC



Note

■A regeneration unit may be needed depending on the operating conditions. Regeneration units → Page 27

<sup>\*1</sup> The value inside the [] represents the value when connecting an electromagnetic brake motor.

<sup>\*2 50</sup> times the rotor inertia.

<sup>\*3</sup> The value when operated in the continuous duty region. When operated in the limited duty region, a maximum of approximately 3 times the current flows.

<sup>\*4</sup> The electromagnetic brake holds position when the power is off. It cannot be used for braking applications.

# **Standard Type**

#### Frame Size 85 mm

#### Specifications

**₽**30 €

Motor Product Name		Single Shaft		AZXM960AC
WOLDI FIDUUCI I	vanie	With Electromagnetic E	Brake	AZXM960MC
Driver Product I	Name			AZXD-S□
Rated Output Po	ower		W	600
Rated Speed			r/min	3000
Max. Speed			r/min	5500
Rated Torque			Nm	1.91
Maximum Insta	ntanoous Torquo	Single-Phase 200-240 VAC	Nm	3.82
Maximum Instantaneous Torque		Three-Phase 200-240 VAC	Nm	7.16
Rotor Inertia			J: kgm <sup>2</sup>	0.948×10 <sup>-4</sup> [1.03×10 <sup>-4</sup> ]* <sup>1</sup>
Permissible Ine	rtia*2		J: kgm <sup>2</sup>	47.4×10 <sup>-4</sup>
Resolution			P/R	100~10000 (Factory setting 1000)
Detector				Mechanical Multi-Turn Absolute Encoder 1 Turn: 16 bit Multi-Turn: ±900 rotations (1800 rotations)
	Main Dower Cumply	Input Voltage		Single-Phase/Three-Phase 200-240 VAC —15 - +6% 50/60 Hz
Power Supply	Main Power Supply	Rated Current*3	Α	Single-Phase: 7.1 Three-Phase: 3.9
Input	Control Power	Input Voltage		24 VDC±5%
	Supply	Input Current	Α	0.27 [0.62]*1
		Туре		Power Off Activated Type
		Power Supply Input		24 VDC±10%
Electromagneti	c Brake <sup>*4</sup>	Power Consumption	W	8.5
		Rated Current	Α	0.35
		Static Friction Torque	Nm	1.91

A letter indicating the driver type is specified where the box I is located in the product name. Check "List of Combinations" on page 5 for driver product names.

- \*1 The value inside the [] represents the value when connecting an electromagnetic brake motor.
- \*2 50 times the rotor inertia.
- \*3 The value when operated in the continuous duty region. When operated in the limited duty region, a maximum of approximately 4 times the current flows for three-phase input, and a maximum of approximately 2 times the current flows for single-phase input.
- \*4 The electromagnetic brake holds position when the power is off. It cannot be used for braking applications.

  | Note |


When the motor is continuously operated at rating, a heat sink of a capacity at least equivalent to an aluminum plate of the following size is required. **AZXM960**□**C**: 350 mm×350 mm, 10 mm thick

### Speed – Torque Characteristics

#### AZXM960□C

Power supply specification:

Three-phase 200-240 VAC



#### AZXM960□C

Power supply specification:

Single-phase 200-240 VAC



■A regeneration unit may be needed depending on the operating conditions. Regeneration units → Page 27

# **PS** Geared Type

#### Frame Size 90 mm

#### **Specifications**

**₽**1°us (€

Motor Product	Nama	Single Shaft		AZXM940AC-PS5	AZXM940AC-PS10	AZXM940AC-PS25	AZXM960AC-PS5	
WOLDI FIDUUCI	Ivallie	With Electromagneti	c Brake	AZXM940MC-PS5	AZXM940MC-PS10	AZXM940MC-PS25	AZXM960MC-PS5	
Driver Product	Driver Product Name				AZXD-S.			
Rated Output F	Power		W		400		600	
Rated Torque			Nm	5.72	11.4	25.7	8.6	
Maximum Inct	antaneous Torque	Single-Phase 200-240 VAC	Nm	17.1	34.3	77.2	17.2	
Maximum max	antaneous forque	Three-Phase 200-240 VAC	Nm	17.1	34.3	11.2	32.2	
Permissible Sp	eed Range		r/min	0 - 1100	0 - 550	0 - 220	0 - 1100	
Rotor Inertia			J: kgm <sup>2</sup>		0.294×10 <sup>-4</sup> [0.316×10 <sup>-4</sup> ] *1		0.948×10 <sup>-4</sup> [1.03×10 <sup>-4</sup> ] *1	
Inertia*2			J: kgm <sup>2</sup>	0.163×10 <sup>-4</sup>	0.160×10 <sup>-4</sup>	0.175×10 <sup>-4</sup>	0.163×10 <sup>-4</sup>	
Permissible Inc	ertia*³		J: kgm <sup>2</sup>	0.037	0.147	0.919	0.119	
Gear Ratio				5	10	25	5	
Resolution			P/R	500 - 50000 (Factory setting 5000)	1000 - 100000 (Factory setting 10000)	2500 - 250000 (Factory setting 25000)	500 - 50000 (Factory setting 5000)	
Detector				Mechanical Multi-Turn Absolute Encoder 1 Turn: 16 bit Multi-Turn: ±900 rotations (1800 rotations)				
Backlash			arcmin		15	(0.25°)		
	Main Power	Input Voltage			Single-Phase/Three-Phase 200	0-240 VAC −15~+6% 50/6	0 Hz	
Power	Supply	Rated Current*4	А	Siı	ngle-Phase: 5.3 Three-Phase:	3.0	Single-Phase: 7.1 Three-Phase: 3.9	
Supply Input	Control Power	Input Voltage			24 V	DC±5%	,	
	Supply	Input Current	Α		0.27 [0.57]*1		0.27 [0.62]*1	
	Туре			Power Off	Activated Type			
		Power Supply Input		24 VDC±10%				
Electromagnet	ic Brake <b>*</b> ⁵	Power Consumption	W		7.2		8.5	
		Rated Current	Α		0.3		0.35	
		Static Friction Torque	Nm		1.27		1.91	

- A letter indicating the driver type is specified where the box is located in the product name. Check "List of Combinations" on page 5 for driver product names.
- \*1 The value inside the [] represents the value when connecting an electromagnetic brake motor.
- \*2 This is the value of the internal inertia of the gear converted to the motor shaft. \*3 The square of 50 times the rotor inertia  $\times$  the gear ratio.
- \*4 The value when operated in the continuous duty region (the region that can be used at continuous rating).

When operated in the limited duty region (the region used for acceleration and deceleration), the following current flows.

·AZXM940: Approx. 3 times max.

·AZXM960 single-phase: Approx. 2 times max.

•AZXM960 three-phase: Approx. 4 times max. \*5 The electromagnetic brake holds position when the power is off. It cannot be used for braking.

### Speed - Torque Characteristics


#### AZXM940□C-PS5

### AZXM940 C-PS10

AZXM940□C-PS25 Power supply specification: Three-phase/single-phase 200-240 VAC








#### AZXM960□C-PS5

Power supply specification: Three-phase 200-240 VAC



Power supply specification: Single-phase 200-240 VAC



#### Note ■A regeneration unit may be needed depending on the operating conditions. Regeneration units → Page 27

■ Either A (standard) or M (type with an electromagnetic brake) indicating the configuration is specified where the box □ is located in the product name.

### Driver Specifications

Driver Product Name		AZXD-SED	AZXD-SEP	
	Control Input	6 Points, Photocoupler		
	Pulse Output	2 Points, Line Driver		
Interface	Control Output	6 Points, Photocoupler and Open-Collector		
interiace	Power Shut Down Signal Input	2 Points, Photocoupler		
	Power Shut Down Monitor Output	1 Point, Photocouple	r and Open-Collector	
	Field Network	EtherCAT	EtherNet/IP	

#### **Driver Functions**

#### EtherCAT-Compatible

Driver Product Name		AZXD-SED	
Remote I/O	Input	16 Points	
Remote i/O	Output	16 Points	
		Profile Position Mode (PP)	
		Profile Speed Mode (PV)	
Operation Modes		Return-to-Home Mode (HM)	
		Cyclic Synchronous Position Mode (CSP)	
		Cyclic Synchronous Speed Mode (CSV)	
Setting Tool		Support Software MEXEO2	
Coordinates Management Method		Battery-Free Absolute System	
Monitor and Information		As shown in the table below.	
Alarm		0	

#### EtherNet/IP-Compatible

Driver Product N	Name			AZXD-SEP
Number of Posit	tioning Data Sets			256 Points
Remote I/O		Input		16 Points
nemote i/O		Output		16 Points
Setting Tool				Support Software MEXEO2
Coordinates Ma	nagement Method			Battery-Free Absolute System
			Independent Operation	0
		Linked Operation	Sequential Operation	0
	Positioning Operation	Lilikeu Operation	Multi-Speed Operation (Continuous Sequential Operation)	0
		Sequence Control	Loop Operation (Repeating)	0
Operation			Event Jump Operation	0
	Continuous Operation			0
	Datum To Home Opera	Return-To-Home Operation		0
	Return-To-Home Opera	High-Speed Return-to-Home Operation		0
	JOG Operation			0
			Waveform Monitoring	0
			Overload Detection	0
			Overheat Detection (Motor and driver)	0
Monitor and Info	ormation		Position and Speed Information	0
		Temperature Detection (Motor and driver)	0	
-			Motor Load Factor	0
			Distance Traveled / Integrating Distance Traveled	0
Alarm				0

### Communication Specifications

#### EtherCAT-Compatible

Communication Protocol	IEC 61158 Type12		
Physical Layer/Protocol	100 BASE-TX (IEEE 802.3)		
Baud Rate	100 Mbps		
Communication Cycle	-Free Run Mode: 1 ms minSM2 Event Synchronous Mode: 1 ms minDC Mode: 0.25 ms, 0.5 ms, 1 ms, 2 ms, 3 ms, 4 ms, 5 ms, 6 ms, 7 ms, 8 ms, 9 ms, 10 ms		
RJ45×2 (Shield-compatible)  Communication Port/Connector			
Topology	Daisy Chain (Max. 65,535 nodes)		
Process Data	Variable PDO Mapping		
Sync Manager	-SM0: Mailbox Output -SM1: Mailbox Input -SM2: Process Data Output -SM3: Process Data Input		
Mailbox (CoE)	-Emergency Messages -SD0 Request -SD0 Response -SD0 Information		
Synchronous Mode	-Free Run Mode (Asynchronous)) -SM2 Event Synchronous Mode -DC Mode (SYNC0 Event Synchronous)		
Device Profile	IEC 61800-7 CiA402 Drive Profile		


#### EtherNet/IP-Compatible

Communication Protocol		EtherNet/IP (Complies with CT18)
Vendor ID		187: Oriental Motor Co., Ltd
Device Type		43: Generic Device
Baud Rate		10/100 Mbps (Autonegotiation)
Communication Mode		Full Duplex/Half Duplex (Autonegotiation)
Cable Specifications		Shielded Twisted-Pair (STP) Cable Stroke/Cross, Category 5e min. Recommended
Bytes	Output (Scanner→Driver)	40 bytes
bytes	Input (Driver→Scanner)	56 bytes
	Compatible Connections	2
	Connection Type	Exclusive Owner, Input Only
Implicit Communication	Communication Cycle (RPI)	1 - 3200 ms
implicit communication	Connection Type (Scanner→Driver)	Point—to—Point
	Connection Type (Driver→Scanner)	Point—to—Point, Multicast
	Data Reflection Trigger	Cyclic
IP Address Setting Method		IP Address Setting Switch, Parameter, DHCP
Compatible Topologies		Star, Linear, Ring (Device Level Ring)

## General Specifications

		Motor	Driver	
Thermal Class		130 (B)	-	
Insulation Resistance		100 M $\Omega$ or more when a 500 VDC megger is applied between the following places: -Case–Motor Winding -Case–Electromagnetic Brake Winding*1	$100~M\Omega$ or more when a 500 VDC megger is applied between the following places: -Protective Earth Terminal–Main Power Supply Terminal -Encoder Connector–Main Power Supply Terminal -I/O Signal Terminal–Main Power Supply Terminal	
Dielectric Strength		Sufficient to withstand the following for 1 minute:  -Case—Motor Winding  1.5 kVAC 50 Hz or 60 Hz  -Case—Electromagnetic Brake Winding*  1.0 kVAC 50 Hz or 60 Hz	Sufficient to withstand the following for 1 minute: -Protective Earth Terminal—Main Power Supply Terminal 1.5 kVAC 50 Hz or 60 Hz -Encoder Connector—Main Power Supply Terminal 1.8 kVAC 50 Hz or 60 Hz -VO Signal Terminal—Main Power Supply Terminal 1.8 kVAC 50 Hz or 60 Hz	
Operating Environment	Ambient Temperature	0 - +40°C (Non-freezing)*2	$0\sim+55^{\circ}$ C (Non-freezing)*3 [If the <b>AZXM960</b> is used at single-phase 200-240 VAC, then $0\sim+50^{\circ}$ C]*3	
(In operation)	Ambient Humidity	85% or less (Non-condensing)		
	Atmosphere	No corrosive gases or dust. The product should not be exposed to water, oil or other liquids.		
Degree of Protection		IP65 (excluding installation surfaces and connectors)	IP10	
Shaft Runout		0.05T.I.R. (mm)*4	-	
Concentricity of Installation Pilot to the Shaft		0.075T.I.R. (mm)*4	_	
Perpendicularity of Installar Surface to the Shaft	tion	0.075T.I.R. (mm) <sup>‡-4</sup>	-	

- \*1 Only for products with an electromagnetic brake
- $\ensuremath{\$2}$  Based on Oriental Motor's internal measurement conditions
- \$3 When a heat sink of a capacity at least equivalent to an aluminum plate with a size of 200 $\times$ 200 mm and 2 mm thickness
- \*4 T.I.R. (Total Indicator Reading): The total dial gauge reading when the measurement section is rotated once around the reference axis center.



#### Note

Separate the motor and driver when measuring insulation resistance or performing a dielectric voltage withstand test. Also, do not perform these tests on the absolute sensor part of the motor.

#### Permissible Radial Load and Permissible Axial Load


Unit: N

	Mater			Permissible Radial Load				Permissible	
Туре	Motor Product Name	Product Name	Gear Ratio	Distance from Shaft End mm					Axial
Flame Size	Traine dize			0	5	10	15	20	Load
Standard Type	60 mm	AZXM640	-	230	245	262	281	304	98
85 mm	AZXM960	-	376	392	408	426	446	147	
<b>PS</b> Geared Type			5	380	420	470	540	630	
	90 mm AZXM940	10	480	530	590	680	790	600	
		25	650	720	810	920	1070	]	
		AZXM960	5	380	420	470	540	630	600

- ■The product names are listed such that the product names are distinguishable.
- When the **PS** geared type with an input speed of 3000 r/min operates with either a radial load or axial load,
  - a lifetime of 10000 hours is the permissible value.
  - For the life of gearhead, please contact the nearest Oriental Motor sales office, or visit the Oriental Motor website.

#### Radial Load and Axial Load

Distance from Shaft End [mm]




#### Rotation Direction

This indicates the rotation direction when viewed from the output shaft side of the motor.

Please check the following table for the rotation direction of the output gear shaft when viewed from the output shaft side of the standard type motor.

Туре	Gear Ratio	When Viewed from the Output Shaft Side of the Motor Rotation Direction
PS Geared Type	Total Gear Ratio	Same Direction





### Dimensions (Unit = mm)


Motor

#### Frame Size 60 mm 400 W

Product Name	L	Mass [kg]	
AZXM640AC	121.5	1.5	· •
Encoder Cable $\phi 6$	Mot Mot	or Cable φ6.5	60 50±0.35 4×φ4.5 Thru  (Lu) \$200-980 (Lu) \$200-980 50 ±0.35 127  27
500654-0609 (Molex)	3507	79-1 (TE Connec	tivity)

#### Frame Size 85 mm 600 W


Product Name	L	Mass [kg]
AZXM960AC	132	3.1



### $\lozenge$ Standard Type with an Electromagnetic Brake


#### Frame Size 60 mm 400 W

Product Name	L	Mass [kg]
AZXM640MC	163.5	2.0



#### Frame Size 85 mm 600 W


Product Name	L	Mass [kg]
AZXM960MC	174	4.0



#### ◇PS Geared Type


#### Frame Size 90 mm 400 W

Product Name	Gear Ratio	L1	L2	Mass [kg]
AZXM940AC-PS	5, 10	61	201.5	3.5
AZAM94UAC-P3	25	88.3	229	4.4



#### Frame Size 90 mm 600 W


Product Name	Gear Ratio	L1	L2	Mass [kg]
AZXM960AC-PS	5	61	226	5.3



#### ◇PS Geared Type with Electromagnetic Brake


#### Frame Size 90 mm 400 W

Product Name	Gear Ratio	L1	L2	Mass [kg]
AZXM940MC-PS■	5, 10	61	243.5	4.0
AZAMI94UMC-P3	25	88.3	270.5	4.9



#### Frame Size 90 mm 600 W


Product Name	Gear Ratio	L1	L2	Mass [kg]
AZXM960MC-PS	5	61	268	6.2



 $<sup>\</sup>blacksquare$  A number indicating the gear ratio is specified where the box  $\blacksquare$  is located in the product name.

#### Driver

Туре	Product Name	Mass [kg]
EtherCAT-Compatible	AZXD-SED	1.5
EtherNet/IP Compatible	AZXD-SEP	1.5



#### Included Items

 $Control\ Power\ Supply\ Input/Electromagnetic\ Brake\ Connection/Regeneration\ Unit\ Thermal\ Input/Power\ Shut\ Down\ Signal\ I/O\ Connector\ (CN1)$ 

· Connector: DFMC1,5/7-ST-3,5-LR (Phoenix Contact)

Connector for Main Power/Regeneration Unit (CN4)

- · Connector: 1-2271454-6 (TE Connectivity)
- · Connector Wiring Lever

I/O Signals Connector (CN7)


· Connector: DFMC1,5/12-ST-3,5 (Phoenix Contact)

#### Connection and Operation


#### Names of Driver Parts

For details about each function, refer to the operating manual for the **AZX** Series. Either download operating manuals from the Oriental Motor website or contact your nearest Oriental Motor sales office.

#### 



#### 



#### USB Cable Connection

A USB cable is required for connecting the driver to the computer on which the support software **MEXEO2** is installed. Use a USB cable with the following specifications.


	<u> </u>
Specifications	USB 2.0 (Full Speed)
Cables	Length: 3 m or less Configuration: A to mini B

#### Connection Diagrams

#### **♦** EtherCAT-Compatible

#### • Diagram for Connection with Current Sink Output Circuit

#### • Diagram for Connection with Current Source Output Circuit




#### Note

- Use 24 VDC for the input signals.
- Use output signal at 12~24 VDC 10 mA or less. When the current value exceeds 10 mA, connect an external resistor R0 to reduce the current to 10 mA or less.
- Provide a distance of 200 mm or more between the signal lines and power lines (power supply lines, motor lines).
  - Do not run the signal lines in the same piping as power lines or bundle them with power lines.
- If noise generated by the motor cable or power supply cable causes a problem with the specific wiring or layout, shield the cable or use ferrite cores.

#### 

#### • Diagram for Connection with Current Sink Output Circuit

#### • Diagram for Connection with Current Source Output Circuit




#### Note

- Use 24 VDC for the input signals.
- Use output signal at 12~24 VDC 10 mA or less. When the current value exceeds 10 mA, connect an external resistor R0 to reduce the current to 10 mA or less.
- Provide a distance of 200 mm or more between the signal lines and power lines (power supply lines, motor lines).
  Do not run the signal lines in the same piping as power lines or bundle them with power lines.
- If noise generated by the motor cable or power supply cable causes a problem with the specific wiring or layout, shield the cable or use ferrite cores.

# **Cable**

#### Cable System Configuration

#### Network Compatible Driver




- \*1 Flexible connection cable sets and flexible extension cable sets with excellent durability are also available.
- \*2 Required for motors with an electromagnetic brake.
- \*3 Not supplied.

#### Note

- Up to 3 cables can be used to connect the motor and driver.
- The maximum extension distance between the motor and driver is 20 m.
- The motor cable and electromagnetic brake cable from the motor cannot be connected directly to the driver. When connecting to a driver, use a connection cable.

#### Connection Cable



\*Required for motors with an electromagnetic brake.

#### Note

- Up to 3 cables can be used to connect the motor and driver.
- ■The maximum extension distance between the motor and driver is 20 m.


#### 1 Connection Cable Sets / Flexible Connection Cable Sets

This is a connection cable set used to connect the motor and the driver. Use a flexible extension cable set in applications where the cable is bent and flexed repeatedly. The motor cable and electromagnetic brake cable from the motor cannot be connected directly to the driver. When connecting to a driver, use a connection cable.

#### Product Line

#### 







#### • For Motor / Encoder

Length L [m]	Product Name
1	CC010VXF
2	CC020VXF
3	CC030VXF
5	CC050VXF
7	CC070VXF
10	CC100VXF
15	CC150VXF
20	CC200VXF

#### For Motor / Encoder / Electromagnetic Brake


• For Motor / Encoder /

Length L [m]	Product Name
1	CC010VXFB
2	CC020VXFB
3	CC030VXFB
5	CC050VXFB
7	CC070VXFB
10	CC100VXFB
15	CC150VXFB
20	CC200VXFB

#### **♦** Flexible Connection Cable Sets



#### · For Motor / Encoder / Electromagnetic Brake



Length L [m]	Product Name
1	CC010VXR
2	CC020VXR
3	CC030VXR
5	CC050VXR
7	CC070VXR
10	CC100VXR
15	CC150VXR
20	CC200VXR


# der Electromagnetic Brake Product Name Length L [m]

Driver Side


Length L [m]	Product Name	
1	CC010VXRB	
2	CC020VXRB	
3	CC030VXRB	
5	CC050VXRB	
7	CC070VXRB	
10	CC100VXRB	
15	CC150VXRB	
20	CC200VXRB	
Note on use of flexible cables → Page 26		

#### Dimensions (Unit = mm)


#### 



#### 



#### $\diamondsuit$ Cable for Electromagnetic Brake



<sup>■</sup>Note on use of flexible cables → Page 26

#### 2 Extension Cable Set - Motor Side / Flexible Extension Cable Set - Motor Side

This is a cable to extend the connection cable to the motor. When using an extension, the total length of the cable must be less than 20 m. Use the flexible extension cable set in applications where the cable is bent and flexed repeatedly.

#### Product Line



#### • For Motor / Encoder

Length L [m]	Product Name
1	CC010VXFT
2	CC020VXFT
3	CC030VXFT
5	CC050VXFT
7	CC070VXFT
10	CC100VXFT
15	CC150VXFT

· For Motor / Encoder / Electromagnetic Brake

#### For Motor / Encoder / Electromagnetic Brake

Length L [m]	Product Name
1	CC010VXFBT
2	CC020VXFBT
3	CC030VXFBT
5	CC050VXFBT
7	CC070VXFBT
10	CC100VXFBT
15	CC150VXFBT

#### For Motor / Encoder / Electromagnetic Brake

#### ♦ Flexible Extension Cable Sets · For Motor / Encoder



#### • For Motor / Encoder

Length L [m]	Product Name
1	CC010VXRT
2	CC020VXRT
3	CC030VXRT
5	CC050VXRT
7	CC070VXRT
10	CC100VXRT
15	CC150VXRT

Note on use of flexible cables → Page 26


#### For Motor / Encoder / Electromagnetic Brake

Length L [m]	Product Name
1	CC010VXRBT
2	CC020VXRBT
3	CC030VXRBT
5	CC050VXRBT
7	CC070VXRBT
10	CC100VXRBT
15	CC150VXRBT


■ Note on use of flexible cables → Page 26

#### Dimensions (Unit = mm)


#### $\diamondsuit$ Cable for Motor




#### 



#### 



### Cable for I/O Signals




### **General-Purpose Type**

- Multi-core Shielded Cable
- Unbundled wires on both ends
- Easy shield grounding using ground wire with a round terminal
- The number of lead wire cores can be selected to suit the functions that will be used




Product Name	Length L [m]	Number of Lead Wire Cores	Outer Diameter D [mm]	AWG
CC06D005B-1	0.5			
CC06D010B-1	1	6	ф5.4	24
CC06D015B-1	1.5	0		
CC06D020B-1	2			
CC10D005B-1	0.5	10	ф6.7	
CC10D010B-1	1			
CC10D015B-1	1.5			
CC10D020B-1	2			
CC12D005B-1	0.5	12	ф7.5	
CC12D010B-1	1			
CC12D015B-1	1.5			
CC12D020B-1	2			
CC16D005B-1	0.5	16	ф7.5	
CC16D010B-1	1			
CC16D015B-1	1.5			
CC16D020B-1	2			

#### Dimensions (Unit = mm)



#### Cables for DC Power Supplies

These cables are used to connect the driver and the DC power supply.




#### Product Line

Product Name	Length L [m]
CC02D005-3	0.5
CC02D010-3	1
CC02D015-3	1.5
CC02D020-3	2
CC02D050-3	5



#### Dimensions (Unit = mm)



#### Note on Use of Cables

#### Note when Connecting Connectors

When inserting or removing connectors, always hold the connector.

Pulling on the cable may result in connection faults.

#### ♦ When Inserting the Connector

Hold the connector body and insert as straight as possible. If the connector is angled while inserted, it may result in damage to the terminals or connection faults.

#### **♦ When Removing the Connector**


Disengage the connector's lock and pull straight out. If the connector is disengaged by pulling the cable, it may result in damage to the connector.

#### Notes on Routing of Flexible Cables

Do not bend the cable at the connector. This will apply stress to the connector and the terminal, and may result in connection faults or disconnections.

#### 


Please fix in 2 locations to prevent movement of the connector.



#### ♦ Cable Routing Length and Bend Radius

When routing cables, use an appropriate length that prevents pulling when the cable is moved.

The bend radius must be at least 6 times the cable diameter



#### 

When routing cables inside a cable holder, ensure that the cables do not interfere with each other. This will apply stress to the connector and the terminal, and may result in premature disconnection. Please carefully check the cautions when using cable holders.

#### 

Route the cables so that they do not become twisted. Premature wire breaking may occur if they are bent while twisted.

After routing the wires, use the markings on the surface of the cable to ensure that the cables are not twisted.

# **Peripheral Equipment**

# **Regeneration Unit**

The regenerative power generated by the motor may exceed the driver's regenerative power absorption capacity. In such case, a regeneration unit is connected to the driver to dissipate the regenerative power.

- <Conditions in Which a Regeneration Unit is Likely Required>

  - -Acceleration or deceleration with an inertial load installed

	_
Product Name	
RGB200	

### Specifications

Item	Description
Continuous Regenerative Power	200 W
Resistance Value	50 Ω
Thermal Protector Operating Temperature	Operation: 175±5°C Return: 115±15°C (Normally closed)
Thermal Protector Electrical Rating	227 VAC 8 A 115 VAC 22 A

Install the regeneration unit in a place that has the same heat radiation capability as the heat sink (material: aluminum, 350 $\times$ 350 mm, 3 mm thick).

### **Connector Cover**

#### <Application Example>

This is a resin cover for protecting and securing the connected connector part of the cable.

- · Protection level equivalent to IP20
- · It can be installed after connecting the motors and drivers.
- · It is a structure to secure cables and protect lead wires.
- · It can be attached to the equipment using two mounting holes ( $\phi$ 4.5).



Material: Polyamide

Product Name
MAC-D*
MAC-D02

\*Excluding encoder cable and motor cable

# **Oriental motor**

These products are manufactured at plants certified with the international standards ISO 9001 (for quality assurance) and ISO 14001 for systems of environmental management).

Specifications are subject to change without notice. This catalogue was published in January 2024.

#### **ORIENTAL MOTOR (EUROPA) GmbH**

#### European Headquarters

Schiessstraße 44 40549 Düsseldorf, Germany Tel: 0211 5206700 Fax: 0211 52067099

#### Spanish Office

C/Caléndula 93 - Ed. E - Miniparc III 28109 El Soto de La Moraleja, Alcobendas (Madrid), Spain Tel: +34 918 266 565

#### ORIENTAL MOTOR (UK) LTD.

#### **UK Headquarters**

Unit 5, Faraday Office Park, Rankine Road, Basingstoke, Hampshire RG24 8AH, U.K. Tel: +44 1256 347090 Fax: +44 1256 347099

#### ORIENTAL MOTOR SWITZERLAND AG

#### Switzerland Headquarters

Badenerstrasse 13 5200 Brugg AG, Switzerland Tel: +41 56 560 50 45 Fax: +41 56 560 50 47

#### ORIENTAL MOTOR ITALIA s.r.l.

#### Italy Headquarters

Via XXV Aprile 5 20016 Pero (MI), Italy Tel: +39 2 93906346 Fax: +39 2 93906348

#### ORIENTAL MOTOR (FRANCE) SARL

#### France Headquarters

56, Rue des Hautes Pâtures 92000 Nanterre, France Tel: +33 1 47 86 97 50 Fax: +33 1 47 82 45 16

#### **Customer Service Center**

(Support in German & English)

#### 0080022556622\*

Mon-Thu: 08:00 - 16:30 CET Friday: 08:00 - 15:00 CET \*Free Call Europe

info@orientalmotor.de

